



How to attach Patches

- Pre-heat iron to 120-150 degrees.
- Iron the item to have the patch attached. This will ensure the area where the patch will be going is nice and hot.
- Place the patch on the fabric and apply heat for 8-9 seconds.
- Let the cloth cool down all the way and the patch will be adhered on permanently.

DO NOT iron on leather, suede, or delicate fabrics